

Använd Ctrl + F för att söka efter din kod

Märke	Modell	Produkt nr.	Prod datum
AEG	CCS62000BW	94300519600	20190819
AEG	CCP62001BW	94300529400	20200908
ELECTROLUX	EOB50000X	94971310700	20090710
ELECTROLUX	EOB50000X	94971310701	20090805
ELECTROLUX	EOB50000X	94971310702	20091113
ELECTROLUX	EOB50000X	94971310703	20100902
ELECTROLUX	EOB50000X	94971310704	20110307
ELECTROLUX	EKC60301OW	94300488600	20151204
ELECTROLUX	EKC60301OW	94300488601	20160128
ELECTROLUX	EKC60301OW	94300488700	20151204
ELECTROLUX	EKC60301OW	94300488701	20160323
ELECTROLUX	EKC60109FW	94300489600	20160526
ELECTROLUX	EKC60109FW	94300489601	20161031
ELECTROLUX	EKC60109FW	94300489602	20170928
ELECTROLUX	EKC60109FW	94300489603	20180511
ELECTROLUX	EKC60309FW	94300489700	20160526
ELECTROLUX	EKC60309FW	94300489701	20170302
ELECTROLUX	EKC60309FW	94300489702	20170928
ELECTROLUX	EKC60309FW	94300489703	20180710
ELECTROLUX	EKC60309FW	94300489704	20181126
ELECTROLUX	EKC60309FX	94300489900	20160526
ELECTROLUX	EKC60309FX	94300489901	20160929
ELECTROLUX	EKC60309FX	94300489902	20170828
ELECTROLUX	EKC60309FX	94300489903	20180508
ELECTROLUX	EKC60309FX	94300489904	20181128
ELECTROLUX	EKC60305IW	94300490100	20160520
ELECTROLUX	EKC60305IW	94300490101	20160922
ELECTROLUX	EKC60305IW	94300490102	20170828
ELECTROLUX	EKC60305IW	94300490103	20180508
ELECTROLUX	EKC60305IW	94300490104	20181106
ELECTROLUX	EKC60305IW	94300490200	20160523
ELECTROLUX	EKC60305IW	94300490201	20160920
ELECTROLUX	EKC60305IW	94300490202	20170928
ELECTROLUX	EKC60305IW	94300490203	20180907
ELECTROLUX	EKC60305IW	94300490204	20181120
ELECTROLUX	EKI60305IW	94300490300	20160517
ELECTROLUX	EKI60305IW	94300490301	20161108
ELECTROLUX	EKI60305IW	94300490302	20170824
ELECTROLUX	EKI60305IW	94300490303	20180607
ELECTROLUX	EKI60305IW	94300490304	20181217
ELECTROLUX	EKC60304OW	94300490500	20160513
ELECTROLUX	EKC60304OW	94300490501	20160919
ELECTROLUX	EKC60304OW	94300490502	20170822
ELECTROLUX	EKC60304OW	94300490503	20180710
ELECTROLUX	EKC60304OW	94300490504	20181109
ELECTROLUX	EKI60304OW	94300490600	20160520
ELECTROLUX	EKI60304OW	94300490601	20160919
ELECTROLUX	EKI60304OW	94300490602	20171101

ELECTROLUX	EKI60304OW	94300490603	20181004
ELECTROLUX	EKI60304OW	94300490604	20181212
ELECTROLUX	EKC60303HW	94300490700	20160513
ELECTROLUX	EKC60303HW	94300490701	20160919
ELECTROLUX	EKC60303HW	94300490702	20170829
ELECTROLUX	EKC60303HW	94300490703	20180514
ELECTROLUX	EKC60303HW	94300490704	20181116
ELECTROLUX	EKC60303HX	94300490800	20160511
ELECTROLUX	EKI60303HW	94300490900	20160520
ELECTROLUX	EKI60303HW	94300490901	20170613
ELECTROLUX	EKI60303HW	94300490903	20180906
ELECTROLUX	EKI60303HW	94300490904	20181031
ELECTROLUX	EKI60303HX	94300491000	20160520
ELECTROLUX	EKI60303HX	94300491001	20170413
ELECTROLUX	EKI60303HX	94300491002	20170822
ELECTROLUX	EKI60303HX	94300491003	20180529
ELECTROLUX	EKI60303HX	94300491004	20190906
ELECTROLUX	EKC60304OW	94300491700	20160624
ELECTROLUX	EKC60304OW	94300491701	20161125
ELECTROLUX	EKC60304OW	94300491703	20180810
ELECTROLUX	EKC60304OW	94300491704	20190207
ELECTROLUX	EKI60304OW	94300491800	20160802
ELECTROLUX	EKI60304OW	94300491801	20161209
ELECTROLUX	EKI60304OW	94300491802	20170829
ELECTROLUX	EKI60304OW	94300491803	20180516
ELECTROLUX	EKI60304OW	94300491804	20181120
ELECTROLUX	EKC60310JW	94300493600	20160825
ELECTROLUX	EKC60310JW	94300493601	20161005
ELECTROLUX	EKC60310JW	94300493602	20171103
ELECTROLUX	EKC60310JW	94300493603	20180523
ELECTROLUX	EKC60310JW	94300493604	20181218
ELECTROLUX	EKI60310JW	94300493701	20160919
ELECTROLUX	EKC60309FW	94300493800	20160829
ELECTROLUX	EKC60309FW	94300493801	20160929
ELECTROLUX	EKC60309FW	94300493802	20170828
ELECTROLUX	EKC60309FW	94300493803	20180620
ELECTROLUX	EKC60309FW	94300493804	20181030
ELECTROLUX	EKC60309FX	94300493900	20160829
ELECTROLUX	EKC60309FX	94300493901	20160929
ELECTROLUX	EKC60309FX	94300493902	20170914
ELECTROLUX	EKC60309FX	94300493903	20180511
ELECTROLUX	EKC60309FX	94300493904	20181030
ELECTROLUX	EKC60109FW	94300512500	20181102
ELECTROLUX	EKK60500OW	94300516200	20190806
ELECTROLUX	EKS60100OW	94300516400	20190726
ELECTROLUX	EKS62100OW	94300516500	20190819
ELECTROLUX	EKS62100OW	94300516600	20190806
ELECTROLUX	EOB301X	94406479200	20170410
ELECTROLUX	EOB301W	94406479300	20170518
ELECTROLUX	EOB301X	94406489800	20181213

ELECTROLUX	EOB301X	94406489801	20190812
ELECTROLUX	EOB301W	94406489900	20181220
ELECTROLUX	EOB301W	94406489901	20190410
ELECTROLUX	EKB101X	94406809100	20191002
ELECTROLUX	EKB101W	94406809200	20191002
ELEKTRO HELIOS	SU4500W	94971310800	20090703
ELEKTRO HELIOS	SU4500W	94971310801	20090803
ELEKTRO HELIOS	SU4500X	94971310900	20090703
ELEKTRO HELIOS	SU4500X	94971310901	20090831
ELEKTRO HELIOS	SU4500W	94971310802	20100921
ELEKTRO HELIOS	SU4500X	94971310902	20100729
ELEKTRO HELIOS	SU4700X	94971315800	20100406
ELEKTRO HELIOS	SU4700X	94971315802	20110316
ELEKTRO HELIOS	SU4500W	94971393900	20110920
ELEKTRO HELIOS	SU4500X	94971394000	20110920
ELEKTRO HELIOS	SU4500X	94971394001	20120228
IKEA	LOV3 201.521.96	94406450000	20090901
IKEA	LOV3 201.521.9	94971303800	20090330
IKEA	LOV3 201.521.9	94971303801	20090803
IKEA	LOV3X 901.522.06	94971303900	20090330
IKEA	LOV3X 901.522.06	94971303901	20090803
IKEA	LOV3 001.521.9	94971304000	20090330
IKEA	FOV9 - 301 562 12	94971304400	20090410
IKEA	FOV9 - 301 562 12	94971304401	20090728
IKEA	FOV9 / 201.522.38	94971304500	20090601
IKEA	FOV9 - 601 562 20	94971304600	20090417
IKEA	FOV9S - 501 562 11	94971304700	20090410
IKEA	FOV9S / 201.562.17	94971304800	20090601
IKEA	FOV9S - 401 562 21	94971304900	20090417
IKEA	FOV10P - 901 562 09	94971305000	20090410
IKEA	FOV10P / 401.562.16	94971305100	20090601
IKEA	FOV10P - 401 522 37	94971305200	20090417
IKEA	LOV3 401 667 9	94971305800	20090330
IKEA	UCG30 - 201 511 30	94972220200	20090410
IKEA	UCG30 - 201 511 30	94972220201	20090806
IKEA	UCG30 - 901 514 57	94972220300	20090417
IKEA	UCG30 - 701 514 58	94972220400	20090417
IKEA	UCG30 201 511 30	94406400000	20090925
IKEA	UCG30 201-511-30	94406400001	20100804
IKEA	UCG30 201 511 30	94406400002	20100804
IKEA	UCG30 201 511 30	94406400003	20120111
IKEA	UCG30 201-511-30	94406400004	20120917
IKEA	UCG30 901 514 57	94406400100	20090925
IKEA	UCG30 901 514 57	94406400102	20100806
IKEA	UCG30 901-514-57	94406400103	20120214
IKEA	UCG30 701 514 58	94406400200	20090925
IKEA	UCG30 701-514-58	94406400201	20100809
IKEA	UCG30 701-514-58	94406400202	20120110
IKEA	LOV3 201-521-96	94406450001	20100615
IKEA	LOV3 201-521-96	94406450002	20100802

IKEA	LOV3 201-521-96	94406450003	20120109
IKEA	LOV3 201-521-96	94406450004	20120921
IKEA	LOV3 201-521-96	94406450005	20121214
IKEA	LOV3X 901.522.06	94406450100	20090901
IKEA	LOV3X 901.522.06	94406450101	20100802
IKEA	LOV3X 901-522-06	94406450102	20100802
IKEA	LOV3X 901-522-06	94406450103	20120123
IKEA	LOV3 001 521 97	94406450200	20090925
IKEA	LOV3 001 521 97	94406450202	20100806
IKEA	LOV3 001-521-97	94406450203	20120124
IKEA	LOV3 001-521-97	94406450204	20120921
IKEA	LOV3 401 667 91	94406450300	20090925
IKEA	LOV3 401-667-91	94406450301	20100721
IKEA	LOV3 401-667-91	94406450302	20120110
IKEA	FOV9 301-562-12	94406450400	20090925
IKEA	FOV9 301-562-12	94406450401	20100616
IKEA	FOV9 301-562-12	94406450402	20100802
IKEA	FOV9 201 522 38	94406450500	20090925
IKEA	FOV9 201-522-38	94406450501	20100721
IKEA	FOV9 201-522-38	94406450502	20100820
IKEA	FOV9 201-522-38	94406450503	20110816
IKEA	FOV9 601 562 20	94406450600	20090925
IKEA	FOV9 601-562-20	94406450601	20100722
IKEA	FOV10P 901 562 09	94406500000	20090925
IKEA	FOV10P 901-562-09	94406500001	20100617
IKEA	FOV10P 901-562-09	94406500002	20100728
IKEA	FOV10P 401 562 16	94406500100	20090925
IKEA	FOV10P 401-562-16	94406500101	20100811
IKEA	FOV10P 401-562-16	94406500102	20110303
IKEA	FOV10P 401 522 37	94406500200	20090925
IKEA	FOV10P 401-522-37	94406500201	20100621
IKEA	FOV10P 401-522-37	94406500202	20100729
IKEA	LOV3 201-521-96	94406450006	20151128
IKEA	LOV3 001-521-97	94406450205	20151208
IKEA	OV12 202-451-67	94406452900	20120910
IKEA	OV12 202-451-67	94406452901	20130218
IKEA	OV12 802-451-69	94406453000	20120910
IKEA	OV12 802-451-69	94406453001	20130222
IKEA	OV12 002-451-68	94406453100	20120910
IKEA	OV12 002-451-68	94406453101	20130219
IKEA	OV13 302-451-76	94406453200	20120910
IKEA	OV13 302-451-76	94406453201	20130221
IKEA	OV13 602-451-70	94406453300	20120910
IKEA	OV13 602-451-70	94406453301	20130313
IKEA	OV13 902-451-78	94406453400	20120910
IKEA	OV13 902-451-78	94406453401	20130222
IKEA	OV14 102-451-77	94406453500	20120910
IKEA	OV14 102-451-77	94406453501	20130221
IKEA	OV14 002-451-73	94406453600	20120910
IKEA	OV14 002-451-73	94406453601	20130222

IKEA	OV14 202-451-72	94406453700	20120910
IKEA	OV14 202-451-72	94406453701	20130222
IKEA	OV15 502-451-75	94406453800	20120910
IKEA	OV15 502-451-75	94406453801	20130221
IKEA	OV15 802-451-74	94406453900	20120910
IKEA	OV15 802-451-74	94406453901	20130222
IKEA	OV15 402-451-71	94406454000	20120910
IKEA	OV15 402-451-71	94406454001	20130222
IKEA	OV16 302-451-81	94406454100	20120910
IKEA	OV16 302-451-81	94406454101	20130218
IKEA	OV16 102-451-82	94406454200	20120910
IKEA	OV16 102-451-82	94406454201	20130222
IKEA	OV16 702-451-84	94406454300	20120910
IKEA	OV16 702-451-84	94406454301	20130222
IKEA	OV17 602-451-89	94406454400	20120910
IKEA	OV17 602-451-89	94406454401	20130219
IKEA	OV17 802-451-88	94406454500	20120910
IKEA	OV17 802-451-88	94406454501	20130222
IKEA	OV18 202-451-86	94406454600	20120910
IKEA	OV18 202-451-86	94406454601	20130221
IKEA	OV18 402-451-90	94406454700	20120910
IKEA	OV18 402-451-90	94406454701	20130221
IKEA	OV18 202-451-91	94406454800	20120910
IKEA	OV18 202-451-91	94406454801	20130405
IKEA	OV19 002-451-92	94406454900	20120910
IKEA	OV19 002-451-92	94406454901	20130219
IKEA	OV19 602-451-94	94406455000	20120910
IKEA	OV19 602-451-94	94406455001	20130222
IKEA	OV19 802-451-93	94406455100	20120910
IKEA	OV19 802-451-93	94406455101	20130219
IKEA	OV20 302-451-95	94406455200	20120910
IKEA	OV20 302-451-95	94406455201	20130221
IKEA	OV20 902-451-97	94406455300	20120910
IKEA	OV20 902-451-97	94406455301	20130222
IKEA	OV20 102-451-96	94406455400	20120910
IKEA	OV20 102-451-96	94406455401	20130222
IKEA	OV21 702-451-98	94406455500	20120910
IKEA	OV21 702-451-98	94406455501	20130218
IKEA	OV22 502-451-99	94406455600	20120910
IKEA	OV22 502-451-99	94406455601	20130226
IKEA	RAFFINERA 402.847.04	94406459700	20140102
IKEA	RUTINERAD 902.847.06	94406459800	20140102
IKEA	RUTINERAD 102.847.05	94406459900	20140102
IKEA	BEJUBLAD 202.847.00	94406460000	20140102
IKEA	GORLIG 10300786	94406466100	20150108
IKEA	GORLIG 10300786	94406466101	20151202
IKEA	GORLIG 70300793	94406466200	20150108
IKEA	OV33 70300793	94406466201	20161107
IKEA	GORLIG 90300792	94406466300	20150108
IKEA	GORLIG 90300792	94406466301	20151222

IKEA	GORLIG 30322061	94406471500	20150612
IKEA	GORLIG 30322061	94406471501	20160212
IKEA	LAGAN OV3 60322050	94406473000	20150612
IKEA	LAGAN OV3 60322050	94406473001	20160126
IKEA	GORLIG 20411703	94406483600	20180425
IKEA	GORLIG 20411703	94406483601	20190408
IKEA	GORLIG 20411859	94406483700	20180508
IKEA	GORLIG 20411859	94406483701	20190528
IKEA	GORLIG 00411860	94406483800	20180425
IKEA	GORLIG 00411860	94406483801	20190408
IKEA	GORLIG 80411861	94406483900	20190401
IKEA	GORLIG 80411861	94406483901	20190416
IKEA	GORLIG 80413228	94406484900	20180410
IKEA	GORLIG 80413228	94406484901	20200121
IKEA	LAGAN 50416921	94406485000	20180426
IKEA	LAGAN 50416921	94406485001	20190408
IKEA	LAGAN 70416920	94406485100	20180507
IKEA	LAGAN 70416920	94406485101	20190410
IKEA	LAGAN 30416922	94406485300	20190401
IKEA	LAGAN 30416922	94406485301	20190521
IKEA	LAGAN 90416919	94406485400	20180424
IKEA	LAGAN 90416919	94406485401	20190709
IKEA	LAGAN 50443076	94406804001	20190529
IKEA	GORLIG 70443075	94406804101	20190529
ZANKER	ZOB581XQ	94971310501	20091020
ZANUSSI	ZOB342W	94971310100	20090702
ZANUSSI	ZOB342W	94971310101	20090825
ZANUSSI	ZOB342X	94971310201	20090907
ZANUSSI	ZOB481NQ	94971310301	20090827
ZANUSSI	ZOB481XQ	94971310400	20090702
ZANUSSI	ZOB481XQ	94971310401	20090819
ZANUSSI	ZOB581XQ	94971310500	20090727
ZANUSSI	ZOB382X	94971310600	20090706
ZANUSSI	ZOB382X	94971310601	20090806
ZANUSSI	ZOU342W	94972222300	20090702
ZANUSSI	ZOU342W	94972222301	20090911
ZANUSSI	ZOU342X	94972222400	20090708
ZANUSSI	ZOU342X	94972222401	20090826
ZANUSSI	ZOU481XQ	94972222600	20090702
ZANUSSI	ZOU481XQ	94972222601	20090828
ZANUSSI	ZOB342W	94971310102	20101223
ZANUSSI	ZOB342X	94971310200	20091016
ZANUSSI	ZOB342X	94971310202	20100823
ZANUSSI	ZOB481NQ	94971310302	20100806
ZANUSSI	ZOB481XQ	94971310402	20100216
ZANUSSI	ZOB481XQ	94971310403	20100824
ZANUSSI	ZOB581XQ	94971310502	20100803
ZANUSSI	ZOB581XQ	94971310503	20100803
ZANUSSI	ZOB382X	94971310602	20100803
ZANUSSI	ZYB461X	94971316000	20100308

ZANUSSI	ZYB461X	94971316001	20101020
ZANUSSI	ZYB461X	94971316002	20110315
ZANUSSI	ZYB461X	94971316003	20110731
ZANUSSI	ZOB342W	94971393300	20110919
ZANUSSI	ZOB342X	94971393400	20110919
ZANUSSI	ZOB342X	94971393401	20120109
ZANUSSI	ZOB481NQ	94971393500	20110923
ZANUSSI	ZOB481XQ	94971393600	20110923
ZANUSSI	ZOB581XQ	94971393700	20110923
ZANUSSI	ZOB382X	94971393800	20110922
ZANUSSI	ZOB382X	94971393801	20111216
ZANUSSI	ZOU342W	94972222302	20100730
ZANUSSI	ZOU342X	94972222402	20100730
ZANUSSI	ZOU481NQ	94972222501	20091007
ZANUSSI	ZOU481XQ	94972222602	20100831
ZANUSSI	ZOU342W	949722227600	20110922
ZANUSSI	ZOU342X	949722227700	20110922
ZANUSSI	ZOU342X	949722227701	20120215
ZANUSSI	ZOU481XQ	949722227800	20110921
ZANUSSI	ZCI64001WA	94300485900	20150804
ZANUSSI	ZCI64001WA	94300485901	20160127
ZANUSSI	ZCV65011WA	94300486000	20150630
ZANUSSI	ZCV65011WA	94300486001	20160125
ZANUSSI	ZCV65011WA	94300486002	20161108
ZANUSSI	ZCV65011WA	94300486003	20170822
ZANUSSI	ZCV65011WA	94300486004	20180613
ZANUSSI	ZCV65011WA	94300486005	20190118
ZANUSSI	ZCV67001WA	94300516800	20190702
ZANUSSI	ZOB442X	94406462900	20140617